

# Ebola Packaging Kit Instructions

The Ebola kit will be delivered with the following components:



1x

**PGII Certified 55 gallon  
Poly Drum**



1x

**Package of  
absorbent**



1x

**Spray bottle of EPA  
registered disinfectant**



2x

**Red plastic inner liners**  
that meet the standard for  
thickness, tear resistance,  
and puncture resistance.



3x

**Bag ties**



3x

**Labels for poly drum:**

- Infection Substance
- UN 2814
- Package Orientation Arrows

## Packaging for waste contaminated with or suspected of being contaminated with Ebola must be packaged according to the method described below:

1. Notify [care@danielshealth.com](mailto:care@danielshealth.com) (CC your Daniels Health Account Manager and [compliance@danielshealth.com](mailto:compliance@danielshealth.com)) of suspected or confirmed patient with Ebola.
2. Tip absorbent into the base of the 55 gallon drum.
3. Place the waste into the red plastic inner liner.
4. Seal the bag utilizing the liner bag tie.
5. Spray the exterior surface of the liner with disinfectant.
6. Place the liner inside a second red plastic inner liner to ensure waste is 'double bagged'.
7. Seal the second liner with a plastic bag tie.
8. Spray the outside of the second liner with disinfectant.
9. Place the waste contained in the liners into the 55 gallon drum.
10. Place the lid on the 55 gallon drum.
11. Secure the lid to the drum with the locking ring, ensuring locking ring is tight and secure.
12. Spray the outside of the drum with disinfectant, ensuring to spray all surface areas.
13. Affix "Infectious Substance", "UN 2814" and "Package Orientation Arrows" labels on the exterior of the drum. Labels shall be displayed next to each other, within 6 inches of one another.
14. Remove drum and place in the appropriate designated storage location.
15. Contact [care@danielshealth.com](mailto:care@danielshealth.com) (CC your Daniels Health Account Manager and [compliance@danielshealth.com](mailto:compliance@danielshealth.com)) to schedule a collection of the drum(s).

